



**WARNING**  
**READ THIS BEFORE INSTALLING**  
**FAILURE TO COMPLY WITH THESE**  
**INSTRUCTION MAY CAUSE SERIOUS**  
**INJURY OR DEATH**

We recommend the following

- 1) that the seat be mounted to the roll cage or structural member of the frame
- 2) That you bolt the seat in six (6) places
  - a. Four(4) on the seat bottom
  - b. Two (2) just below the shoulder belt holes as wide as possible

**We DO NOT recommend the use of stock sliders and adjusters as these can let go in a high impact crash.**